

Ágata L

Table

Technical file



SPARE PARTS



RECYCLABLE



ASSEMBLY

Description

Frame

Made with a hardened aluminum tube of 50 mm diameter and 2 mm thickness.

Screws

Manufactured in AISI 304 stainless steel that offers great resistance to corrosion in marine environments.

Paint

Powder paint based on polyester resins that offers great resistance to light and outdoor environments in accordance with European regulations EC 850/2004, EU 519/2012 and EU 2015/2030.

Accessories

Caps and studs made of PVC.

Tabletop

Manufactured with welded aluminum profiles of 1,5 mm thickness.


Security

Product certified according to European safety regulations EN-581-1:2017 and EN-581-2:2017.

Ágata L

Table

Capacity



A - 94 cm C - 180 cm
B - 75 cm D - 94 cm

20 kg


Package	Units	Measures	Weight	Volume
Box	1 u.	187x99x115 cm	21 kg	2,12 m ³
Pallet	17 u.	190x102x223 cm	453 kg	4,36 m ³

Loading capacity	Mega trailer	Cont. 20'	Cont. 40'	Cont. 40' High Cube
Ágata L	- u.	102 u.	204 u.	228 u.

Finishes

Frame


Matte texture



White Aluminum

Tabletop

Matte texture



White Aluminum



Ágata L

Table

Maintenance plan

Weekly

Visual check of the general condition, removing dirt and ensuring there are no broken parts or damage that could be a danger to users.

Monthly

Check that the aluminum structure has no damage or deep scratches.

Check the structural strength and stability.

Check the condition of the caps and studs.

Annual

Repair any damage to the paint.

Replace any worn or damaged parts.

Wintering and storage

Clean with soapy water and a soft cloth.

Remove damp stains, sand and seawater.

Store vertically in a dry place.

Observations

- Always use Balliu spare parts.
- Balliu does not manufacture parts for other brands.
- If the product is subject to heavy use, maintenance checks must be carried out more frequently.
- Do not use the product until maintenance is completed.
- Do not use aggressive chemicals to clean the product.
- Always use products with a neutral pH.
- Use a soft cloth to clean the product.

